



KAWA

Części zamienne do urządzeń: **CIMBALI**



GASTROPARTS Sp. J.


Klonowica 37
87-100 Toruń
tel. +48 56 657 00 68
fax +48 56 657 00 67
gastroparts@gastroparts.pl



CIMBALI - ESPRESSO MACHINES

1
ESPRESSO MACHINES


GROUPS





FILTER HOLDERS



STEAM/WATER TAPS



INLET TAP/LEVEL INDICATOR/MANOMETERS



CIMBALI - ESPRESSO MACHINES

1
ESPRESSO MACHINES

BOILER VARIOUS

529312 (3/8") 529316 (3/8") 529307 (1/4")

529303 (1/4") 529304 (1/4") 529361 (1/4")

529361 (1/4") 529349 (3/8")

528005

400214 (L = 140 mm)
400020 (L = 150 mm)

M-15
417015 (1 GR, 230 VAC, 2700 W)
417016 (2 GR, 230 VAC, 4000 W)
417098 (3 GR, 230 VAC, 5000 W)

M20-M25-M30-M32
529484 (FIBER)
528004 (PTFE)

417011 (1 GR, 230 VAC, 1800 W)
417013 (ALINA, 230 VAC, 2850 W)
417012 (2 GR, 230 VAC, 3750 W)
417099 (3 GR, 230 VAC, 5790 W)

JUNIOR
417014 (JUNIOR, 1 GR, 230 VAC, 1300 W)

528121 (M20-M25-M30 FIBER)
528122 (M20-M25-M30 TEFLON)
528120 (M15)

ELECTRICAL COMPONENTS VARIOUS

400209 (DIGMESA) 400004 (GICAR) 400256

400259 (DIGMESA)
400257 (GICAR)
400258

541021 (SIRAI, 30 A, 3 POLES) 541724 (SIRAI, 20 A, 3 POLES) 541723 (SIRAI, 20 A, 2 POLES) 541453 (PARKER) 541020

370062 (PARKER)
370061 (LUCIFER)

370057 (230 VAC-PARKER)
370050 (24 VAC-PARKER)
370053 (230 VAC-LUCIFER)
370054 (24 VAC-LUCIFER)
370051 (24 VDC-LUCIFER)

371029 (230 VAC-PARKER)
371036 (24 VAC-PARKER)
371031 (230 VAC-LUCIFER)
371032 (24 VAC-LUCIFER)
371043 (24 VDC-LUCIFER)

370059 (230 VAC-1/4"-PARKER)
370219 (24 VAC-1/4"-PARKER)

370206 (230 VAC-1/8"-PARKER)
370066 (24 VAC-1/8"-PARKER)

371029 (230 VAC-PARKER)
371036 (24 VAC-PARKER)

370168 (230 VAC-1/8"-SIRAI)
370064 (24 VAC-1/8"-SIRAI)

371071 (230 VAC-SIRAI)
371070 (24 VAC-SIRAI)

371090 371095 (VITON) 371100 371091

ELECTRICAL COMPONENTS VARIOUS



380213 (230 VAC)
380401 (12 VDC)
380405 (12 VAC)



380403 (230 VAC)
380404 (24 VAC)
380400 (12 VDC)



390324



346030



346024



346025



345269



345150



345149

112006



112005



345090
(PUSH BUTTON, 2 POLES)

345033

(SWITCH, 2 POLES)

345033

(SWITCH, 2 POLES)




301015
(PUSH BUTTON, 2 POLES)



359142
(GREEN)



359143
(YELLOW)



400335 (M20)



400336 (M30)



www.gastroparts.pl



GASTROPARTS Sp. J.

Klonowica 37
87-100 Toruń
tel. +48 56 657 00 68
fax +48 56 657 00 67
gastroparts@gastroparts.pl

