



KAWA

Części zamienne do urządzeń: **ELEKTRA**




GASTROPARTS Sp. J.

Klonowica 37
87-100 Toruń
tel. +48 56 657 00 68
fax +48 56 657 00 67
gastroparts@gastroparts.pl



GROUP



FILTER HOLDERS




ELEKTRA – ESPRESSO MACHINES

1
ESPRESSO MACHINES


GROUP/FILTER HOLDERS HOME



STEAM/WATER TAPS




STEAM/WATER TAPS/LEVEL INDICATOR/VALVES




STEAM/WATER TAPS/LEVEL INDICATOR HOME


S1, S1C, SX, SXC



ELECTRICAL COMPONENTS SIXTIES



ELECTRICAL COMPONENTS VARIOUS



ELECTRICAL COMPONENTS VARIOUS



390324



345722 (1 POLE)



345720 (2 POLES)



346020



346031



346032



346019



301001
(RED)



301060



301038 (GREEN)



301039 (RED)



301040 (SWITCH)
301044
(PUSH BUTTON)



359237
(RED)



359238
(GREEN)



359240
(GOLD)



359242
(CHROMED)



417175
(800 W
230 VAC)



528182



400361
(OLD-00384035)



www.gastroparts.pl



GASTROPARTS Sp. J.

Klonowica 37
87-100 Toruń
tel. +48 56 657 00 68
fax +48 56 657 00 67
gastroparts@gastroparts.pl

