




OBRÓBKA TERMICZNA

Części zamienne do urządzeń: ASCOBLOC



GASTROPARTS Sp. J.

Klonowica 37
87-100 Toruń
tel. +48 56 657 00 68
fax +48 56 657 00 67
gastroparts@gastroparts.pl




TABLE OF CONTENTS

Open tops (gas/electric)



page 4

Ovens (gas/electric)




page 5

Fry tops (gas/electric)



page 5


Bains-marie (electric)



page 6

TABLE OF CONTENTS

Fryers (gas/electric)




page 6

Tilting bratt pans (electric)



page 7

Boiling pans (electric)



page 8

Suitable for Ascobloc


A Open tops (gas)



| Item | Order | Description | Model | OEM |
|------|--------|---------------------|----------------|---------|
| 1 | 104501 | burner cover (C) | | 9146383 |
| 2 | 104500 | burner base (C) | AGH210/218/410 | 9146387 |
| 3 | 104511 | burner gasket | AGH413/417/418 | 9146393 |
| 4 | 104502 | Venturi (C) | AGH610/613 | 9146385 |
| 5 | 104520 | air aeration sleeve | AGH617/618 | - |



| Item | Order | Description | Model | OEM |
|------|--------|---------------------|----------------|---------|
| 1 | 104541 | burner cover (D) | | 9146389 |
| 2 | 104505 | burner base (D) | AGH210/218/410 | 9146388 |
| 3 | 104511 | burner gasket | AGH413/417/418 | 9146393 |
| 4 | 104504 | Venturi (D) | AGH610/613 | 9146391 |
| 5 | 104521 | air aeration sleeve | AGH617/618 | - |



| Item | Order | Description | Model | OEM |
|------|--------|-------------------------|-------------|-----|
| 1 | 101529 | pilot burner (complete) | | - |
| 2 | 101848 | cover | | - |
| 3 | 101582 | upper part | newe series | - |
| 4 | 101587 | gasket | | - |



| Item | Order | Description | Model | OEM |
|------|--------|-------------------------------|-------------|-----|
| 1 | 101584 | cap (upper part) | | - |
| 2 | 101583 | ignition piece | | - |
| 3 | 101586 | lower part | newe series | - |
| 4 | 101284 | olive, 4mm | | - |
| 5 | 101285 | union screw, M8x1 | | - |
| 6 | 101585 | thermocouple screw connection | | - |



| Item | Order | Description | Model | OEM |
|------|--------|----------------------|----------------|-----------|
| 1 | 101831 | ignition piece inlet | | 9146405 |
| 2 | 101830 | ignition piece | AGH210/218/410 | 9146406 |
| 3 | 101839 | thermocouple inlet | AGH413/417/418 | 9146407 |
| 4 | 101587 | gasket | AGH610/613 | 9146402 |
| 5 | 101842 | cover | AGH617/618 | 918430000 |



| Item | Order | Description | Model | OEM |
|------|--------|-----------------------------|----------------|---------|
| 1 | 101843 | base plate pilot burner (C) | AGH210/218/410 | 9146409 |
| 2 | 101844 | base plate pilot burner (D) | AGH413/417/418 | 9146401 |
| 3 | 101835 | pilot burner lower part (C) | AGH610/613 | 9146410 |
| 4 | 101834 | pilot burner lower part (D) | AGH617/618 | 9146403 |




| Item | Order | Description | Model | OEM |
|------|--------|---------------------|----------------|---------|
| 1 | 102218 | thermocouple, 320mm | | 9096024 |
| 1 | 102220 | thermocouple, 600mm | AGH210/218/410 | 9096025 |
| 2 | n.l.a. | gas tap (EGA) | AGH413/417/418 | 9146372 |
| 2 | n.l.a. | gas tap (EGA) | AGH610/613 | 9146372 |
| 3 | 101671 | gas tap (PEL) | AGH617/618 | 9146369 |
| | | | | 9146372 |
| | | | | 9146369 |



| Item | Order | Description | Model | OEM |
|------|--------|-------------|----------------|---------|
| 1 | 110189 | knob | AGH210/218/410 | 9297035 |
| 2 | 110550 | symbol EGA | AGH413/417/418 | 9297026 |
| 3 | 110558 | symbol PEL | AGH610/613 | - |
| | | | AGH617/618 | - |

Open tops (electric)




| Item | Order | Description | Model | OEM |
|------|--------|--|------------|---------|
| 1 | 416893 | cooker (double), 540 x 260mm, 5200W/230V | AEH210/218 | 9174102 |
| 2 | 300172 | 5-position switch | AEH410/413 | 9173302 |
| 3 | 110189 | knob | AEH610/613 | 9297035 |
| 4 | 111553 | symbol | AEH418/618 | 9297025 |
| 5 | 359165 | signal lamp green | | 9295408 |


Open tops/Ceramic (electrical)



| Item | Order | Description | Model | OEM |
|------|--------|------------------------|--------------------------|---------|
| 1 | 490132 | 2100W/230V | AEH300/500 | 9174100 |
| 2 | 490028 | 2100W/230V (2-circuit) | AEH503/508 AEH700/703 | 8181713 |
| 3 | 359165 | signal lamp | AEH708/308 | 9295408 |




| Item | Order | Description | Model | OEM |
|------|--------|-----------------------------|--------------------------|---------|
| 1 | 380016 | energy regulator, 2-circuit | AEH300/500 | 8183237 |
| 2 | 300172 | 5-position switch | AEH503/508 AEH700/703 | 9173302 |
| 3 | 300004 | 7-position switch | AEH708/308 | 9295403 |



| Item | Order | Description | Model | OEM |
|------|--------|-------------------------|------------|---------|
| 1 | 110189 | knob | AEH300/500 | 9297035 |
| 2 | 111555 | symbol energy regulator | AEH503/508 | 9297022 |
| 3 | 110553 | symbol 5-tacts | AEH700/703 | 9297025 |
| 4 | 110552 | symbol seven tast | AEH708/308 | 9297024 |

Ovens (gas)



| Item | Order | Description | Model | OEM |
|------|--------|----------------|--------|---------|
| 1 | 105636 | burner | AGH417 | 8152719 |
| 2 | n.l.a. | gas thermostat | AGH617 | 9146370 |
| 3 | 102223 | thermocouple | - | - |



| Item | Order | Description | Model | OEM |
|------|--------|--------------|--------|---------|
| 1 | 100058 | pilot burner | AGH417 | 9290540 |
| 2 | 110189 | knob | AGH617 | 9297035 |
| 3 | 110547 | symbol | - | 9294238 |

Ovens (electric)




| Item | Order | Description | Model | OEM |
|------|--------|-------------------------|--------|---------|
| 1 | 415995 | 1500W/400V | AEH413 | 9294281 |
| 2 | 359165 | signal lamp/green, 230V | AEH613 | 9295408 |
| 3 | 359198 | signal lamp/white, 400V | AEH503 | 9295409 |
| 4 | 390483 | contact thermostat | AEH703 | 9294101 |



| Item | Order | Description | Model | OEM |
|------|--------|------------------------|--------|---------|
| 1 | 375408 | thermostat with switch | AEH413 | 9295400 |
| 2 | 110189 | knob | AEH613 | 9297035 |
| 3 | 110549 | symbol | AEH703 | 9294127 |

Ovens (mechanical)



| Item | Order | Description | Model | OEM |
|------|--------|--------------------------|------------------------|-----------|
| 1 | 900391 | door seal/upper | - | 127751.05 |
| 2 | 900390 | door seal/side | AGH417/617 | 127750.05 |
| 3 | 700187 | torsion spring | AEH413/613/ 503/703 | 9294387 |
| 4 | 601052 | fan with transverse flow | - | 8178463 |


Fry tops (gas)



| Item | Order | Description | Model | OEM |
|------|--------|---------------------|--------|---------|
| 1 | 104501 | burner cover (C) | - | 9146383 |
| 2 | 104500 | burner base (C) | AGB230 | 9146387 |
| 3 | 104511 | burner gasket | AGB430 | 9146393 |
| 4 | 104502 | Venturi (C) | AGB238 | 9146385 |
| 5 | 104520 | air aeration sleeve | AGB438 | - |




| Item | Order | Description | Model | OEM |
|------|--------|----------------|--------|---------|
| 1 | n.l.a. | thermostat EGA | AGB230 | 9146399 |
| 2 | 110189 | knob | AGB430 | 9297035 |
| 3 | 110547 | symbol | AGB238 | 9294219 |
| | | | AGB438 | |



| Item | Order | Description | Model | OEM |
|------|--------|-----------------------|--------|---------|
| 1 | 102218 | thermocouple | AGB230 | 9296024 |
| 2 | 100085 | pilot burner | AGB430 | 9264282 |
| 3 | 100007 | piezoelectric igniter | AGB238 | 9296035 |
| | | | AGB438 | |

Fry tops (electric)




| Item | Order | Description | Model | OEM |
|------|--------|-------------------------------|--------|---------|
| 1 | 416897 | 3500W/400V | AEB230 | 8160350 |
| 2 | 375505 | thermostat (limiter function) | AEB430 | 8174681 |
| 3 | 359165 | signal lamp green 230V | AEB238 | 9295408 |
| 4 | 359198 | signal lamp white 400V | AEB438 | 9295409 |



| Item | Order | Description | Model | OEM |
|------|--------|------------------------|--------|---------|
| 1 | 375408 | thermostat with switch | AEB230 | 9295400 |
| 2 | 110189 | knob | AEB430 | 9297035 |
| 3 | 110530 | symbol | AEB238 | 9297016 |
| | | | AEB438 | |


Bains-marie (electric)



| Item | Order | Description | Model | OEM |
|------|--------|-------------------------------|--------------------------|---------|
| 1 | 416912 | 750W/230V | AEW250 | 8160351 |
| 2 | 375505 | thermostat (limiter function) | AEW450/452 AEW400/408 | 8174681 |
| 3 | 359165 | signal lamp/green | AEW250/450 | 9295408 |
| 4 | 359166 | signal lamp/white | AEW400/452 AEW408 | 9295407 |




| Item | Order | Description | Model | OEM |
|------|--------|------------------------|------------|---------|
| 1 | 375406 | thermostat with switch | AEW250 | 9295433 |
| 2 | 110189 | knob | AEW450/452 | 9297035 |
| 3 | 110545 | symbol | AEW400/408 | 9297019 |



| Item | Order | Description | Model | OEM |
|------|--------|------------------|--------|-----------|
| 1 | 380486 | level relay, ENS | AEW400 | 9177191 |
| 2 | 400697 | level sensor | AEW408 | 915000648 |

Fryers (gas)



| Item | Order | Description | Model | OEM |
|------|----------|-------------------|--------------------------|-----------|
| 1 | 104380 | burner | | 127678.05 |
| 2 | n. l. a. | thermostat EGA | AGF124/224 AGF128/228 | 9146371 |
| 3 | 375423 | safety thermostat | | 9296108 |




| Item | Order | Description | Model | OEM |
|------|--------|-------------|------------|---------|
| 1 | 110189 | knob | AGF124/224 | 9297035 |
| 2 | 110543 | symbol | AGF128/228 | 9294219 |




| Item | Order | Description | Model | OEM |
|------|--------|-----------------------|------------|---------|
| 1 | 100085 | pilot burner | AGF124/224 | 9294282 |
| 2 | 102089 | thermocouple | AGF128/228 | 9296034 |
| 3 | 100007 | piezoelectric igniter | | 9296035 |

Fryers (electric)



| Item | Order | Description | Model | OEM |
|------|--------|-------------------|------------------|---------|
| 1 | 415591 | 2000W/230V | | 9294087 |
| 2 | 375421 | safety thermostat | AEF124 AEF224 | 8152102 |
| 3 | 359165 | signal lamp/green | AEF128 | 9295408 |
| 4 | 359166 | signal lamp/white | | 9295407 |



| Item | Order | Description | Model | OEM |
|------|--------|-------------|--------|---------|
| 1 | 300179 | switch | AEF124 | 9295405 |
| 2 | 110189 | knob | AEF224 | 9297035 |
| 3 | 110544 | symbol | AEF128 | 8145407 |




| Item | Order | Description | Model | OEM |
|------|--------|-------------|--------|---------|
| 1 | 375422 | thermostat | AEF124 | 8152105 |
| 2 | 110189 | knob | AEF224 | 9297035 |
| 3 | 110536 | symbol | AEF128 | 9297020 |



| Item | Order | Description | Model | OEM |
|------|--------|--------------|------------|---------|
| 1 | 345062 | micro switch | AEF124/224 | 8177168 |
| 2 | 970159 | fryer basket | AEF128/494 | 9292205 |


Tilting bratt pans (electric)



| Item | Order | Description | Model | OEM |
|------|--------|-------------------------------|--------|---------|
| 1 | 416897 | 3500W/400V | | 8160350 |
| 2 | 375505 | thermostat (limiter function) | AEP500 | 8174681 |
| 3 | 359165 | signal lamp/green, 230V | AEP508 | 9295408 |
| 4 | 359198 | signal lamp/white, 400V | | 9295409 |



| Item | Order | Description | Model | OEM |
|------|--------|------------------------|--------|---------|
| 1 | 375408 | thermostat with switch | AEP500 | 9295400 |
| 2 | 110189 | knob | AEP508 | 9297035 |
| 3 | 110530 | symbol | | 9297016 |




| Item | Order | Description | Model | OEM |
|------|--------|--------------|--------|---------|
| 1 | 380418 | contactor | AEP500 | 8486100 |
| 2 | 346299 | limit switch | AEP508 | 8486038 |



| Item | Order | Description | Model | OEM |
|------|--------|-----------------|--------|---------|
| 1 | 346271 | push button | | 8486102 |
| 2 | 346272 | push button lit | AEP500 | 8486105 |
| 3 | 346270 | contact element | AEP508 | 8486101 |

Boiling pans (electric)




| Item | Order | Description | Model | OEM |
|------|--------|-------------|--------|---------|
| 1 | 415405 | 6000W/230V | | 9294203 |
| 2 | 418147 | 6000W/230V | AES060 | 9294496 |
| 3 | 415607 | 500W/230V | AES080 | 8181729 |




| Item | Order | Description | Model | OEM |
|------|--------|-----------------|--------|---------|
| 1 | 510562 | O-ring silicone | | 8060842 |
| 2 | 510408 | O-ring - EPDM | AES060 | 9298045 |
| 3 | 550002 | holder | AES080 | 9294008 |



| Item | Order | Description | Model | OEM |
|------|--------|------------------|--------|---------|
| 1 | 380015 | energy regulator | | 8183150 |
| 2 | 110189 | knob | AES060 | 9297035 |
| 3 | 110551 | symbol | AES080 | 9297017 |



| Item | Order | Description | Model | OEM |
|------|--------|-------------|--------|---------|
| 1 | 300113 | switch | | 9296002 |
| 2 | 110189 | knob | AES060 | 9297035 |
| 3 | 110539 | symbol | AES080 | 9298003 |



| Item | Order | Description | Model | OEM |
|------|--------|-------------------|--------|---------|
| 1 | 541016 | pressure switch | | 9296000 |
| 2 | 390143 | safety thermostat | AES060 | 9296084 |
| 3 | 359165 | signal lamp/green | AES080 | 9295408 |
| 4 | 359166 | signal lamp/white | | 9295407 |



| Item | Order | Description | Model | OEM |
|------|--------|--------------|--------|---------|
| 1 | 541343 | manometer | | 8151500 |
| 2 | 514273 | safety valve | AES060 | 8151701 |
| 3 | 514272 | steam trap | AES080 | 8150901 |



| Item | Order | Description | Model | OEM |
|------|--------|--------------|--------|---------|
| 1 | 540887 | inlet pipe | | 8178419 |
| 2 | 540896 | mixing valve | AES060 | 8151603 |
| 3 | 540155 | drain cock | AES080 | 8150301 |




| Pos. | Order | Description | Model | OEM |
|------|--------|----------------------|-------|-----|
| 1 | 540876 | cover rotating joint | | |





www.gastroparts.pl



GASTROPARTS Sp. J.

Klonowica 37
87-100 Toruń
tel. +48 56 657 00 68
fax +48 56 657 00 67
gastroparts@gastroparts.pl

