




OBRÓBKA TERMICZNA

Części zamienne do urządzeń: FABA




GASTROPARTS Sp. J.

Klonowica 37
87-100 Toruń
tel. +48 56 657 00 68
fax +48 56 657 00 67
gastroparts@gastroparts.pl




Toasters



Item	Order	Description	Model	OEM
1	416142	800W/230V	P2/P4	P40004
2	416143	1000W/230V	P3/P6	P404/1
3	416144	300W/115	Maxigrill	PR4G015

Contact grills



Item	Order	Description	Model	OEM
1	416145	1000W/230V (upper)	series „E“ series „S“	PR10003
2	416146	1200W/230V (upper)		PR103/1
3	416147	1500W/230V		PR103/2

Suitable for Faba




Item	Order	Description	Model	OEM
1	345646	switch/lamp (combination)	P2/P3	PR40027
2	345647	switch (double)	Maxigrill	PR4G026
3	359140	signal lamp	P4/P6, Maxigrill	PR10010
4	390096	thermostat	P2/P3/P4/P6	PR40026




Item	Order	Description	Model	OEM
1	390187	safety thermostat	P2/P3/P4/P6, Maxigrill	PR10015
2	360149	timer		PR40014
3	110889	knob		PR40016




Pos.	Order	Description	Model	OEM
1	693047	insulating part		PR405/6 PR405/7




Item	Order	Description	Model	OEM
1	416148	800W/230V (lower)	series „E“ series „S“	PR10013
1	416145	1000W/230V (lower)		PR10003
2	416146	1200W/230V (lower)		PR103/1



Item	Order	Description	Model	OEM
1	416173	850W/230V (lower)	DLV, DLA	PR13007
2	390187	safety thermostat	series „E“/“S“, DLV, DLA	PR10015
3	359140	signal lamp		PR10010
4	359139	signal lamp		PR10006



Item	Order	Description	Model	OEM
1	375002	thermostat, 300 C	series „E“/“S“	PR10009
2	375253	thermostat, 480 C	ceramic DLV	PR13012
3	300124	switch	series „E“/DLV	PR10007
4	110374	knob	DLV, steel DLA	PR10008



Item	Order	Description	Model	OEM
1	700170	spring, 3,8mm	series „S“, DLA	PR10012
2	700171	spring, 3,2mm	series „E“, OLV	PR13032


Pancake devices (gas)



Item	Order	Description	Model	OEM
1	104288	burner cover		PR3G029
2	105086	burner ring	G400D,	PR3G030
3	105087	burner	G400S	PR3G031
4	104289	burner base		PR3G032




Item	Order	Description	Model	OEM
1	100009	piezoelectric igniter		PR3G047
2	100167	electrode	G400D,	PR3G033
3	102121	thermocouple	G400S	PR3G034




Item	Order	Description	Model	OEM
1	101687	thermostat		PR3G044
2	110377	knob	G400D,	PR3G048
3	101728	gasket	G400S	PR3G045
4	101479	supporting arm		PR3G046

Pancake devices (electrical)




Item	Order	Description	Model	OEM
1	416636	2000W/230 V		PR30001
2	390187	safety thermostat		PR10015
3	359140	signal lamp	D3S	PR10010
4	359139	signal lamp		PR10006



Item	Order	Description	Model	OEM
1	300124	switch		PR10007
2	375002	thermostat, 300 C	D3S	PR10009
3	110374	knob		PR10008

Fryers



Item	Order	Description	Model	OEM
1	416150	2800W/230 V	F4	PR70001
2	416151	1600W/230 V	F6/F8	PR70002
3	345645	switch	F4, F6, F8	PR60008
4	359140	signal lamp		PR10010



Item	Order	Description	Model	OEM
1	345032	micro switch		PR70011
2	375263	safety thermostat	F4, F6, F8	PR70008
3	380213	contactor	F6T, F8T	PR70015



Item	Order	Description	Model	OEM
1	375264	thermostat		PR70009
2	110374	knob	F4, F6, F8	PR10008
3	550419	clamp		PR70044
4	550491	clamp		PR70042



Item	Order	Description	Model	OEM
1	970235	basket	F4	PR70003
2	970236	basket	F6, F8	PR70005
3	540747	drain tap	F6, F8	PR70014



www.gastroparts.pl



GASTROPARTS Sp. J.

Klonowica 37
87-100 Toruń
tel. +48 56 657 00 68
fax +48 56 657 00 67
gastroparts@gastroparts.pl

