



OBRÓBKA TERMICZNA

Części zamienne do urządzeń: KING




GASTROPARTS Sp. J.


Klonowica 37
87-100 Toruń
tel. +48 56 657 00 68
fax +48 56 657 00 67
gastroparts@gastroparts.pl



Open tops (electric)



Item	Order	Description	Model	OEM
1	490012	1500W/230 V (145 mm)	KN3	
2	490016	2000W/230 V (180mm)		0101207
3	490085	2500W/230 V (300x300mm)	KNH8	0101204
3	490089	4000W/230 V (300x300mm)		0101205




Item	Order	Description	Model	OEM
1	300004	7-position switch	KN3, KNH8	0101138
2	300007	4-position switch	KNH8	0102134
3	110234	knob (7-position switch)		0112138
4	110232	knob (4-position switch)	KN3, KNH8	0112134



Item	Order	Description	Model	OEM
1	359063	bulb lamp holder		
2	359085	panel/yellow	KN3, KNH8	
3	359088	panel/clear		
4	359602	glow lamp, 230 V		0103170

Ovens (electric)




Item	Order	Description	Model	OEM
1	418247	2000W/230 V		0101063
2	375038	thermostat	KNH8	0102001
3	110245	knob		0112024



Item	Order	Description	Model	OEM
1	359063	bulb lamp holder		
2	359085	panel/yellow	KNH8	
3	359088	panel/clear		
4	359602	glow lamp, 230V		0103170

Fry tops (electric)



Item	Order	Description	Model	OEM
1	480005	300W/230V, 432mm	GN,	0101161
2	375038	thermostat	SP-G4,	0102001
3	110245	knob	SP-G6	0102024




Item	Order	Description	Model	OEM
1	359063	bulb lamp holder		
2	359085	panel/yellow	GN, SP-G4,	
3	359088	panel/clear	SP-G6	
4	359602	glow lamp, 230 V		0103170

Chargrills (electric)




Item	Order	Description	Model	OEM
1	415646	700W/230 V		0101055
2	415647	1000W/230 V	TN	0101056
3	380213	contactor		




Item	Order	Description	Model	OEM
1	380015	energy regulator, 10A		
2	380010	energy regulator, 16A	TN	
3	110236	knob		

Bratt pans (electric)



Item	Order	Description	Model	OEM
1	418248	1200W/230V	SN	0101052
2	415363	3000W/230V		0111051



Item	Order	Description	Model	OEM
1	375038	thermostat	SN	0102001
2	110245	knob		0102024




Item	Order	Description	Model	OEM
1	359063	bulb lamp holder		
2	359085	panel/yellow	SN	
3	359088	panel/clear		
4	359602	glow lamp, 230V		0103170

Bains-marie (electric)



Pos.	Order	Description	Model	OEM
1	415565	1500W/230V	BN	0111092




Item	Order	Description	Model	OEM
1	375143	thermostat		0102002
2	110241	knob	BN	0102025
3	550271	duct		0102099




Item	Order	Description	Model	OEM
1	359063	bulb lamp holder		
2	359085	panel/yellow	BN	
3	359088	panel/clear		
4	359602	glow lamp, 230V		0103170

Fryers (electric)



Item	Order	Description	Model	OEM
1	418239	5700W/3 phases 230 V	MN	0111001
2	n. l. a.	8500W/3 phases 230 V	RN	0111002
3	375013	safety thermostat	MN, RN	0112012



Item	Order	Description	Model	OEM
1	375699	thermostat, 180 C		0112010
2	110242	knob	MN, RN	
3	300021	switch		0102125
4	110231	knob		




Item	Order	Description	Model	OEM
1	359063	bulb lamp holder		
2	359085	panel/yellow	MN, RN	
3	359088	panel/clear		
4	359602	glow lamp, 230V		0103169




Item	Order	Description	Model	OEM
1	970439	Ø240x140mm	MN	0106001
2	970440	Ø285x145mm	RN	0106002

Folding grills (electrical)




Item	Order	Description	Model	OEM
1	415648	666W/230V		0101405
2	375038	thermostat	Turmix 4000, Turmix 8000	0102001
3	110245	knob		0102024

Gyros grills




Item	Order	Description	Model	OEM
1	415642	700W/230V	KG1	0101006
2	418243	1070W/230V	KG2	0101002
3	359625	500W/230V	KG1	0101121




Item	Order	Description	Model	OEM
1	380015	energy regulator	KG1	
2	110236	knob		
3	300004	7-position switch	KG2	
4	110234	knob		



Item	Order	Description	Model	OEM
1	359063	bulb lamp holder		
2	359085	panel/yellow	SN	
3	359088	panel/clear		
4	359602	glow lamp, 230V		0103170




Item	Order	Description	Model	OEM
1	359712	bulb + housing		
2	359724	standard glass	KG2	
3	359611	lamp/40W, E14		



Item	Order	Description	Model	OEM
1	301009	rocker switch	KG1, KG2	
2	500804	gear motor	KG1	01050071
3	500805	gear motor	KG2	01050015

Chicken grills (electrical)



Item	Order	Description	Model	OEM
1	418244	2200W/230V		0101011
2	418245	2800W/230V	KS1	0101012
3	418246	3000W/230V		0101064




Item	Order	Description	Model	OEM
1	301009	rocker switch		
2	301053	rocker switch	KS1, KS2	
3	301012	rocker switch		





www.gastroparts.pl



GASTROPARTS Sp. J.

Klonowica 37
87-100 Toruń
tel. +48 56 657 00 68
fax +48 56 657 00 67
gastroparts@gastroparts.pl

