GASTROPARTS

Tecnoinox

[EN] Cooking

[DE] Kochtechnik

[ES] Cocción

[FR] Cuisson

[IT] Cottura

[PL] Obróbka termiczna

[RU] Термическая обработка

gastroparts@gastroparts.com

tel. +48 56 657 00 66

fb.com/gastroparts.global

GASTROPARTS.COM

TABLE OF CONTENTS

Open tops (gas/electric)

page 4

Ovens (gas/electric)

page 6

Fry tops (gas/electric)

page 7

Lava rock grills (gas)

page 8

Chargrills (gas/electric)



page 9

T

Suitable for Tecnoinox

TABLE OF CONTENTS

Bratt pans/boiling kettles (electrical)



page 10

Pasta cookers (gas/electric)

page 10

Bains-marie (gas/electric)

page 11

Chip scuttles (electric), fryers (gas/electric)

page 12

Small appliances and single devices

page 14

T

Suitable for Tecnoinox

Open tops (gas)



Item	Order	Description	Model	OEM
1	104286	burner cover, 90mm	PC35G/70G/105G, PC5G, PP5G, PF70GG/105GG, PFL70GG/105GG, PF5GG, PFL5GG, PPF5GG, PPFL5GG	00373
2	104285	burner groupper, 90mm		00372
3	104288	burner cover, 120mm		00375
4	104287	burner groupper, 120mm		00374
5	104289	burner base		00377



Item	Order	Description	Model	OEM
1	105376	burner cover	PC5G, PP5G, PF5GG, PFL5GG, PPF5GG, PPFL5GG	00967
2	105377	burner base		00968
3	105378	burner holder		00976
4	105379	aeration sleeve		00969



Item	Order	Description	Model	OEM
1	101396	gas tap	PC35G/70G/105G, PC5G, PP5G, PF70GG/105GG, PFL70GG/105GG, PF5GG, PFL5GG, PPF5GG, PPFL5GG	00369
2	110710	knob		00401
3	102121	thermocouple, 600mm		00367



Item	Order	Description	Model	OEM
1	100009	piezoelectric igniter	PC35G/70G/105G, PC5G, PP5G, PF70GG/105GG, PFL70GG/105GG, PF5GG, PFL5GG, PPF5GG, PPFL5GG	00128
2	100738	electrode		00368



Item	Order	Description	Model	OEM
1	105386	burner cover, 3,3kW	PC35G7/70G7/105G7, PCP70G7/105G7, PF70G7/667, PF105G7/GG7, PFP70GG7/105GG7	01151
2	105387	burner base		01148
3	105388	burner holder		01138
4	105389	aeration sleeve		01141

Item	Order	Description	Model	OEM
1	105390	burner cover, 3,3kW	PC35G7/70G7/105G7, PCP70G7/105G7, PF70G7/667, PF105G7/GG7, PFP70GG7/105GG7	01150
2	105391	burner base		01147
3	105392	burner holder		01139
4	105393	aeration sleeve		01142



Item	Order	Description	Model	OEM
1	105394	burner cover, 7,2kW	PC35G7/70G7/105G7, PCP70G7/105G7, PF70G7/667, PF105G7/GG7, PFP70GG7/105GG7	01149
2	105395	burner base		01146
3	105396	burner holder		01137
4	105397	aeration sleeve		01143

Item	Order	Description	Model	OEM
1	101095	gas tap	PC35G7/70G7/105G7, PCP70G7/105G7, PF70G7/667, PF105G7/GG7, PFP70GG7/105GG7	50014
2	110935	knob		01153
3	102121	thermocouple, 600mm		00367
4	100041	pilot burner		01140

T

Suitable for Tecnoinox



Item	Order	Description	Model	OEM
1	210155	top grate		00376
2	210181	top grate	P_5G	00970
3	210182	top grate	_G7	01144

Open tops/solid tops (gas)

Item	Order	Description	Model	OEM
1	105398	burner	PPC70G7, PPF70GG7	01161
2	105399	jet holder		00414
3	101095	gas tap		50014
4	110935	knob		01153

Item	Order	Description	Model	OEM
1	100046	pilot burner	PPC70G7, PPF70GG7	00119
2	102121	thermocouple, 600 mm		00367
3	100706	electrode		00120

Item	Order	Description	Model	OEM
1	100018	ignition cable	PPC70G7, PPF70GG7	00123
2	100009	piezoelectric igniter		00128

Open tops (electric)



Item	Order	Description	Model	OEM
1	490014	1500 W/230 V-(180)	PC35E/70E, PF70E	00764
2	490016	2000 W/230 V-(180)		00290



Item	Order	Description	Model	OEM
1	490012	1500 W/230 V-(145)	PC35E7, PCR70E7, PCR105E7, PFR70E7, PFR105E7	00764
2	490020	2600 W/230 V-(220)		01107
3	490065	2600 W/230 V-(220x220)	PCS35E7, PCS70E7, PCS105E7, PFS70E7, PFS105E7	01110



Item	Order	Description	Model	OEM
1	300004	7-position switch	650 series, 700 series	00291
2	110711	knob		00289
3	110936	knob		01109
4	359132	signal element		00052
5	359123	insert lamp holder		00053

Open tops/ceramic (electrical)



Item	Order	Description	Model	OEM
1	490117	1800 W/230 V, 1-circuit	PCC35E/70E, PFC70E, PF70E7	00931
2	490118	2400/230 V, 2-circuit		00932



Item	Order	Description	Model	OEM
1	380015	energy regulator, 1-circuit	650 series, 700 series, PCC35E/70E, PFC70E, PFC70E7	00937
2	380027	energy regulator, 2-circuits		00938
3	110708	knob		00287
4	110937	knob		01070
5	359132	signal element		00052
6	359123	insert lamp holder		00053

Ovens (gas)



Item	Order	Description	Model	OEM
1	105403	burner	PF70GG, PF105GG, PF5GG, PPF5GG	00860
2	101694	gas thermostat		00889
3	110938	knob		00917



Item	Order	Description	Model	OEM
1	105405	burner	PFL70GG, PFL105GG, PFL5GG, PPFL5GG	00882
2	101695	gas thermostat		00890
3	110938	knob		00917



Item	Order	Description	Model	OEM
1	102060	thermocouple, 1500 mm, M8	PF70GG/105GG, PF5GG, PPF5GG, PFL5GG, PPFL5GG	00864
2	102067	nut, M8x1		00865
3	100818	electrode		00861
4	100174	ignition cable		00867

Item	Order	Description	Model	OEM
1	101001	ignition unit	PF70GG/105GG, PF5GG, PPF5GG, PFL5GG, PPFL5GG	00862
2	350036	time clock		00570
3	110706	knob		00494

Item	Order	Description	Model	OEM
1	105406	burner	PF70GG7, PFP70GG7, PPF70GG7	01134
2	101172	gas thermostat PEL25		01133
3	110939	knob		01152
4	100046	pilot burner		00119

Item	Order	Description	Model	OEM
1	102060	thermocouple, 1500 mm, M8	PF70GG7, PFP70GG7, PPF70GG7	00864
2	100009	piezoelectric igniter		00128
3	100174	ignition cable		00867
4	100706	electrode		00120

Oven (electrical)

Item	Order	Description	Model	OEM
1	601011	fan	PF70G/0, PF105G/0, PFL105G/0, PFL5G/0, PPF5G/0, PPFL5G/0, PF70E/0	00565
2	415966	2500 W/230 V		00568
3	350036	time clock		00570
4	110706	knob		00494



Item	Order	Description	Model	OEM
1	375002	thermostat	PF70G/0, PF105G/0, PFL105G/0, PFL5G/0, PPF5G/0, PPFL5G/0, PF70E/0	00569
2	300001	switch		00037
3	110707	knob		00495
4	359132	signal lamp		00052
5	359123	insert lamp holder		00053
6	359124	insert lamp holder		00319

Item	Order	Description	Model	OEM
1	359718	bulb holder + bulb	PF70G/0, PF105G/0, PFL105G/0, PFL5G/0, PPF5G/0, PPFL5G/0, PF70E/0	00805
2	359610	bulb		00566
3	359709	lens		-



Item	Order	Description	Model	OEM
1	416601	1000 W/230 V	PFR70E7, PFR105E7, PFS70E7, PFS105E7, PFL70E7, PF70G7, PF105G7	00775
2	345765	switch		01071
3	110940	knob		01059
4	390142	safety thermostat		00305

Item	Order	Description	Model	OEM
1	375183	thermostat	PFR70E7, PFR105E7, PFS70E7, PFS105E7, PFL70E7, PF70G7, PF105G7	00285
2	110941	knob		01060
3	359132	signal element		00052
4	359123	insert lamp holder		00053
5	359124	insert lamp holder		00319

Ovens (mechanical)

Item	Order	Description	Model	OEM
1	690495	hinge/right	PF__	00939
2	690496	hinge/left		00940
3	690497	counter part		00871

Item	Order	Description	Model	OEM
1	690498	hinge/right	PFL__	00803
2	690499	hinge/left		00804
3	690497	counter part		00876



Item	Order	Description	Model	OEM
1	700006	hinge/right	700-series	01067
2	700007	hinge/left		01068
3	700001	counter part		
4	900257	gasket		01061

Fry tops (gas)



Item	Order	Description	Model	OEM
1	104290	burner	ETL35G, FTR35G, FTC35G, FTL70G, FTR70G, FTC70G	00366
2	101396	gas tap		00369
3	110710	knob		00401
4	100855	holder		00411



Item	Order	Description	Model	OEM
1	102121	thermocouple, 600 mm	ETL35G, FTR35G, FTC35G, FTL70G, FTR70G, FTC70G	00363
2	100009	piezoelectric igniter		00128
3	100018	ignition cable		00123
4	100706	electrode		00120



Item	Order	Description	Model	OEM
1	105408	burner	FTL35E7, FTR35E7, FTC35E7, FTL70E7, FTR70E7, FTC70E7	01164
2	100198	pilot burner		01169
3	102121	thermocouple, 400 mm		00367
4	100009	piezoelectric igniter		00128



Item	Order	Description	Model	OEM
1	100018	ignition cable	FTL35E7, FTR35E7, FTC35E7, FTL70E7, FTR70E7, FTC70E7	00123
2	100701	electrode		01168
3	101095	gas tap		50014
4	110935	knob		01153



Item	Order	Description	Model	OEM
1	101696	Eurosit controller	FTC35E7, FTC70E7	01171
2	110943	knob		01172

Fry tops (electric)



Item	Order	Description	Model	OEM
1	416613	3000 W/230 V	FTL35E/2, FTR35/2, FTC35/2, FTL70E/2, FTR70E/2, FTC70E/2	00767
2	375324	safety thermostat, 1-pole		00770
3	375327	thermostat, 1-pole		00769



Item	Order	Description	Model	OEM
1	415290	1300 W/230 V	FTL35E/0-1, FTR35E/0-1, FTC35E/0-1, FTL70E/0, FTR70E/0, FTC70E/0, FTL55E7, FTR55E7, FTC55E7, FTC70E7, FTR70E7, FTC70E7	00286
2	390142	safety thermostat, 3-pole		00305
3	375183	thermostat, 3-pole		00285

Item	Order	Description	Model	OEM
1	300002	switch	650 series	00070
2	110713	knob		00284
3	359132	signal element		00052
4	359123	insert lamp holder		00053
5	110942	knob	700 series	01079

Lava rock grills (gas)



Item	Order	Description	Model	OEM
1	105483	burner	GR35G/G7, GR70G/G7	00539
2	211024	lava rock grid		00543
3	211025	grill grid		00541

T

Suitable for Tecnoinox



Item	Order	Description	Model	OEM
1	101095	gas tap		50014
2	110716	knob	GR35G/70G	00538
3	100043	pilot burner		00119
4	102041	thermocouple, 600 mm, M9x1		00118
5	110935	knob	GR75G7/70G7	01153

Item	Order	Description	Model	OEM
1	100009	piezoelectric igniter	GR35G/G7, GR70G/G7	00128
2	100018	ignition cable		00123
3	100706	electrode		0120

Chargrills (electric)



Item	Order	Description	Model	OEM
1	416601	1000 W/230 V	GR35E/2	00775
2	345285	micro switch		00283



Item	Order	Description	Model	OEM
1	415288	1350 W/230 V	GR35E/0, GR70E/0	00513
2	380204	contactor		6208
3	345254	micro switch		00204



Item	Order	Description	Model	OEM
1	380015	energy regulator	GR35E/0-2, GR70E/0	6501
2	110708	knob		00287
3	359132	signal element		00052
4	359123	insert lamp holder		00053



Item	Order	Description	Model	OEM
1	540259	drain tap	GR35E/0-2, GR70E/0	00080
2	514027	lever		00336
3	110704	handle		00329
4	514006	drain pipe		00079



Item	Order	Description	Model	OEM
1	416618	1650 W/230 V	GR35E7, GR70E7	01111
2	380204	contactor		6208
3	345254	micro switch		00204

Item	Order	Description	Model	OEM
1	380015	energy regulator	GR35E7, GR70E7	00938
2	110937	knob		01070
3	359132	signal element		00052
4	359123	insert lamp holder		00053



Item	Order	Description	Model	OEM
1	540259	drain tap	GR35E7, GR70E7	00080
2	514027	lever		00336
3	110704	handle		00329
4	514006	drain pipe		00079

Bratt pans/chargrills (electrical)



Item	Order	Description	Model	OEM
1	415292	1100W/230V	BR35E, BRS35E	000528
2	375328	safety thermostat		1007
3	380204	contactor		6208



Item	Order	Description	Model	OEM
1	380015	energy regulator	BR35E, BRS35E	00012
2	110708	knob		00287
3	359132	signal element		00052
4	359123	insert lamp holder		00053

Pasta cookers (gas)



Item	Order	Description	Model	OEM
1	105407	burner	CP35G/G, CP35G7, CP70G7	00587
2	101095	gas tap		50014
3	110716	knob	CP35G	00538
4	110935	knob	CP35G7, CP70G7	01153

Item	Order	Description	Model	OEM
1	100046	pilot burner	CP35G/G, CP35G7, CP70G7	00119
2	102121	thermocouple, 600mm		00367
3	100706	electrode		00120

Item	Order	Description	Model	OEM
1	100009	piezoelectric igniter	CP35G/G, CP35G7, CP70G7	00128
2	100018	ignition cable		00123

Pasta cookers (electric)



Item	Order	Description	Model	OEM
1	416619	1650W/230V	CP35E (until 9/2003)	00595
2	416629	1650W/230V	CP35E (from 9/2003), CP__E7	01250
3	375328	safety thermostat	CP35E), CP__E7	1007
4	359132	signal element		00052
5	359123	insert lamp holder		00053



Item	Order	Description	Model	OEM
1	300002	switch	CP35 (until 9/2003)	00070
2	375630	thermostat		1207
3	110241	knob		00598

T

Suitable for Tecnoinox



Item	Order	Description	Model	OEM
1	345765	switch	CP35 (from 9/2003) CP__E7	01071
2	110232	knob		-
3	110944	knob		01249

Pasta cookers (mechanical)

Item	Order	Description	Model	OEM
1	514034	drain tap	universal	00579
2	514035	inlet tap		00583

Item	Order	Description	Model	OEM
1	970385	145x145x200 (1/6R)	CP35__ CP70__	00605
2	970386	145x145x200 (1/6L)		00604
3	970387	145x290x200 (1/3)		00606
4	970388	290x290x200 (2/3)		00603

Bains-marie (gas)

Item	Order	Description	Model	OEM
1	104291	burner	BM35G, BM70G	00420
2	101396	gas tap		00369
3	110710	knob		00401
4	102121	thermocouple, 600mm		00367



Item	Order	Description	Model	OEM
1	100009	piezoelectric igniter	BM35G, BM70G	00128
2	100018	ignition cable		00123
3	100706	electrode		00120
4	100855	holder		00411



Item	Order	Description	Model	OEM
1	104291	burner	BM35G7, BM70G7	00420
2	101095	gas tap		50014
3	110935	knob		01153
4	100046	pilot burner		00119

Item	Order	Description	Model	OEM
1	102121	thermocouple, 600mm	BM35G7, BM70G7	00367
2	100009	piezoelectric igniter		00128
3	100018	ignition cable		00123
4	100706	electrode		00120

Bains-marie (electric)



Item	Order	Description	Model	OEM
1	415293	1300W/230V	BM35E, BM70E, BM35E7, BM70E7	00269
2	375250	safety thermostat		00427
3	359132	signal element		00052
4	359123	insert lamp holder		00053



Item	Order	Description	Model	OEM
1	375143	thermostat	BM35E/70E, BM35E7/70E7	00274
2	300001	switch		00037
3	110712	knob	BM35E/70E	00268
4	110945	knob	BM35E7/70E7	01085

T
Suitable for Tecnoinox

Bains-marie (mechanical)



Item	Order	Description	Model	OEM
1	540259	drain tap	BM35E, BM70E, BM35E7, BM70E7	0080
2	514027	lever		00336
3	110704	handle		00329
4	514006	drain pipe		00079

Chip scuttles (electric)



Item	Order	Description	Model	OEM
1	415103	650 W/230 V	SP35E	00288
1	415104	1000 W/230 V	SP35E7	01098
2	359132	signal element	SP35E, SP35E7	00052
3	359123	insert lamp holder		00053
4	380015	energy regulator		6501
5	110708	knob	SP35E	00287
6	110937	knob	SP35E7	01070

Fryers (gas)



Item	Order	Description	Model	OEM
1	104293	burner	FR35G, FR70G	00440
2	100046	pilot burner		00445
3	105409	burner	FRS35G7, FRS70G7	01184
4	100858	pilot burner		01187



Item	Order	Description	Model	OEM
1	390060	safety thermostat	FR35G, FR70G, FRS35G7, FRS70G7	00450
2	101188	Eurosit controller		00446
3	101711	adapter		00447
4	110714	knob	FR35G/70G, FRS35G7/70G7	00448
5	110943	knob		01172

Item	Order	Description	Model	OEM
1	102041	thermocouple, 600 mm	FR35G, FR70G, FRS35G7, FRS70G7	00118
2	100706	electrode		00120
3	100018	ignition cable		00123
4	100009	piezoelectric igniter		00128

Fryers (electric)

Item	Order	Description	Model	OEM
1	416659	3000 W/230 V	FR35E/2, FR70E/2	00772
2	415291	2000 W/230 V	FR35E/0-1, FR35E7, FR70E/0, FR70E7	00282
3	416660	3600 W/230 V	FRS35E7, FRS70E7	01276



Item	Order	Description	Model	OEM
1	345127	micro switch	universal	00283
2	375254	safety thermostat, 1-pole	FR_/2	00031
3	390113	safety thermostat, 3-pole	FR_/0-1, FRS_/0	00063
4	380403	relay		00774



Item	Order	Description	Model	OEM
1	359132	signal element	universal	00052
2	359123	insert lamp holder		00053
3	359124	insert lamp holder		00319
4	375309	thermostat, 1-pole	FR_/2	00779
5	390056	thermostat, 3-pole	FR_/0-1, FRS_/0	00281

T

Suitable for Tecnoinox



Item	Order	Description	Model	OEM
1	300002	switch	universal	00070
2	110715	knob	FR35E, FR70E	00280
3	110946	knob	FR35E7/70E7, FRS35E7/70E7	01121

Fryers (mechanical)



Item	Order	Description	Model	OEM
1	540259	drain tap	FR_	00080
2	514027	lever		00336
3	110704	handle		00329
4	514006	drain pipe		00079

Pos.	Order	Description	Model	OEM
1	514034	drain tap	FRS_	00579

Pos.	Order	Description	Model	OEM
1	970139	270x210x100	FR	120575
2	970147	290x220x110	FRS	00678 220620
3	970420	290x110x110		RC01295000

T

Suitable for Tecnoinox

Toasters



Item	Order	Description	Model	OEM
1	415281	1000 W/230 V	TE3, TE6	00006
2	415280	1000 W/230 V	TSP	00171
3	415279	1500 W/230 V	TS1, TS2	00613



Item	Order	Description	Model	OEM
1	301003	switch	TE3, TS1, TS2	04702, 00021
2	301036	protecting cover		-
3	350032	timer, 15min	TE3, TSP, TS1, TS2	00022, 00713
4	110709	knob		00086, 01113

Item	Order	Description	Model	OEM
1	380015	energy regulator	TE6, TSP, TS1, TS2	06501, 00012
2	110701	knob		06301
3	359031	signal lamp	TE3, TE6	00011
4	380403	relay	TS1, TS2, TSP	01213

Salamander (gas)



Item	Order	Description	Model	OEM
1	100046	pilot burner	SG_	00114
2	105427	burner		00117

Item	Order	Description	Model	OEM
1	101087	gas tap	SG_	00126
2	110080	knob		00127
3	110082	symbol		

Item	Order	Description	Model	OEM
1	102041	thermocouple, 600 mm	SG	00118
2	100706	electrode		00120
3	100018	ignition knob		00123
4	100009	piezoelectric igniter		00128

Salamander (electric)



Item	Order	Description	Model	OEM
1	415622	2000 W/230 V	SEL1, SEL2, SEF1, SEF2	00109
1	415349	2000 W/400 V		-
2	415620	2200 W/230 V	SE40	-
3	416653	2200 W/230 V		03804



Item	Order	Description	Model	OEM
1	415621	2200 W/230 V		-
1	415348	2200 W/400 V	SE60	-
2	416654	2200 W/230 V		03706
3	415625	1000 W/230 V	SE80	03708

Item	Order	Description	Model	OEM
1	380015	energy regulator	SE40, SE60, SE80	06501
2	110701	knob		06301
3	359031	signal lamp		06601
4	380204	contactor	SE80	06208

T

Suitable for Tecnoinox

Salamander (electric)



Item	Order	Description	Model	OEM
1	416655	2000 W/230 V	QSE40	01029
2	416656	4000 W/230 V	QSE60	01030



Item	Order	Description	Model	OEM
1	400952	p.c.b.	QSE40	01014
2	693150	fascia		01016
3	400953	p.c.b.	QSE60	01015
4	693151	fascia		01017



Item	Order	Description	Model	OEM
1	345636	switch with potentiometer	QSE40	01028
2	110732	knob	QSE60	01011

Chicken grills



Item	Order	Description	Model	OEM
1	416657	1500 W/230 V	GC16	00243
2	601103	motor/complete		00229 + 00228
3	360328	switch clock		00240



Item	Order	Description	Model	OEM
1	359710	lamp holder	GC16	00218
2	359617	quartz lamp		00217
3	693152	glass		00213
4	345981	switch		00200



Item	Order	Description	Model	OEM
1	375318	safety thermostat	GC16	00238
2	345107	micro switch		00204
3	380204	contactor		06208
4	380373	overload switch		00239

Hot cupboards



Item	Order	Description	Model	OEM
1	415622	2000 W/230 V	EV16	00109
2	601103	motor, complete		00229 + 00228
3	345981	switch		00200



Item	Order	Description	Model	OEM
1	375143	thermostat		00274
2	110712	knob		00268
3	359659	lamp, complete		00275

Fryers

Item	Order	Description	Model	OEM
1	415282	2200 W/23V	FR4, FR4+4	00049
2	415283	3000 W/230 V		00054
3	415284	3400 W/230 V	FR6, FR7 (3,4 kW)	00067

Item	Order	Description	Model	OEM
1	415285	1200 W/230 V	FR6, FR7 (3,6 kW)	00073
2	415286	1500 W/230 V	FR6, FR7 (4,5 kW)	00075
3	415287	2000 W/230 V	FR6, FR7 (6,0 kW)	00142

T

Suitable for Tecnoinox



Item	Order	Description	Model	OEM
1	375255	thermostat, 1-pole	FR4, FR4+4, FR6 (230 V), FR7 (230 V)	00038
2	550060	retainer		
3	300001	switch, 2-pole		00037
4	110702	knob		00035



Item	Order	Description	Model	OEM
1	375256	thermostat, 3-pole	FR6 (400 V), FR7 (400 V)	00064
2	550060	retainer		
3	300002	switch		00070
4	110702	knob		00035



Item	Order	Description	Model	OEM
1	375254	safety thermostat, 1-pole	FR4, FR4+4, FR6 (230 V), FR7 (230 V)	00031
2	300092	limit switch, 1-pole		00092
3	390113	safety thermostat, 3-pole	FR6 (400 V), FR7 (400 V)	00063
4	345127	limit switch, 3-pole		00039

Item	Order	Description	Model	OEM
1	359132	signal element	FR4, FR4+4, FR6, FR7	00052
2	359123	lamp holder/green		00053
3	359124	lamp holder/yellow		00034

Item	Order	Description	Model	OEM
1	970188	basket	FR4	00024
2	970194	basket	FR6	00055
3	970147	basket	FR7	00076

Item	Order	Description	Model	OEM
1	540259	drain tap	FR4, FR4+4, FR6, FR7	00080
2	514006	drain pipe		00079

T

Suitable for Tecnoinox

GASTROPARTS.COM

© 2020 Gastroparts Sp. J. All rights reserved.